

## Westermo MA45 Switch Settings

To configure the MA45 for use with S-series and X-series ACUs the internal switch settings must be configured as shown below:-

### Switch S2 Settings – Data control/transmission settings

Switch	Position	
	X-Series	S-Series
1	N/A	ON
2	N/A	ON
3	N/A	OFF
4	N/A	ON
5	N/A	OFF
6	OFF	OFF
7	ON	OFF
8	N/A	OFF

### Switch S3 Settings – Termination with fail-safe

Switch	Position	
	X-Series	S-Series
1	ON	ON
2	ON	ON
3	OFF	ON
4	OFF	ON

## Réglages du Westermo MA45

Pour configurer le MA45 lors de son utilisation avec une UCA série S ou X, les switches doivent être positionnés de la manière suivante:

### Réglages du switch S2 – Paramétrages du contrôle des données et de la transmission :

	Position du switch	
	Série X	Série S
1	N/A	ON
2	N/A	ON
3	N/A	OFF
4	N/A	ON
5	N/A	OFF
6	OFF	OFF
7	ON	OFF
8	N/A	OFF

### Réglages du Switch S3– Terminaison de bus avec secours

	Position du switch	
	Série X	Série S
1	ON	ON
2	ON	ON
3	OFF	ON
4	OFF	ON

## Configuración de los interruptores para el Conversor Westermo MA45

Configuración del conversor MA45 para ser utilizado con los concentradores de la Serie-S y la Serie-X de TDSi.

### Posición de los interruptores S2- Control Datos y Transmisión

	Posición interruptor	
	Serie-X	Serie-S
1	N/A	ON
2	N/A	ON
3	N/A	OFF
4	N/A	ON
5	N/A	OFF
6	OFF	OFF
7	ON	OFF
8	N/A	OFF

### Posición de los interruptores S3

	Posición interruptor	
	Serie-X	Serie-S
1	ON	ON
2	ON	ON
3	OFF	ON
4	OFF	ON