



# Microsoft® Active Directory Integration

Integration between the physical and logical access world can enhance your security and reduce time in managing both systems. By providing a seamless link between EXgarde and the Active Directory, the access control system can be automatically updated when changes are made within Microsoft Active Directory.

Furthermore, your logical system can be further secured by restricting login if people aren't in the building. This has the added benefit of preventing tailgating thereby increasing security further and ensuring you have a true record of staff in the building.

The AD module runs as a service on the system, which, coupled with a configuration tool allows you to select which domain and tree within AD you want to use. This allows those people that work remotely via secure links to not be affected by the physical access system.

## Key Features

### Fully configurable fields.

Provides flexibility for how you use the AD store.

### Import users from AD.

Saves duplicating work to import users into EXgarde.

### Select Group, Container or OU to import from.

Allows freedom to import what you want and match your structure.

### Define default access group and initial location.

Saves having to define this within EXgarde for the majority of users.

### Monitor OU or Container.

Allows EXgarde to be kept in sync with changes to users in an OU or Container<sup>1</sup>.

### Lock users AD account when they leave the building.

Increases PC logon security and prevents tailgating<sup>2</sup>.

### Suspend Access card on account lock.

Manage the access credentials from the AD store.

### Add or Delete keyholders in EXgarde automatically.

Manage the keyholders based upon AD additions and deletions.

<sup>1</sup>A maximum of 5 items (OU or containers) can be monitored.

<sup>2</sup>Users who tailgate will not be able to logon.



Microsoft

Active Directory

## Ordering Information

Part Number	Description
4420-2408	Active Directory Integration

## System Requirements

- Minimum operating system of Windows 7 PRO or Server 2008.
- Minimum of EXgarde Pro software installed.
- Additional workstation licence.