



IndigoVision



IndigoVision TDSi EXgarde Integration

Seamlessly combining IndigoVision's security management solution with TDSi's EXgarde Software, the newly developed integration allows alarms from TDSi systems to link directly with IndigoVision, resulting in a single user interface - control centre.

With the view of decreasing operator response times, this integration can trigger live video, move PTZ cameras, start recordings, acknowledge TDSi EXgarde alarms and send notification emails automatically.

TDSi System Software Requirements	TDSi EXgarde Pro 4.5.2 and TDSi EXgarde SDK 4.8.0.0 with an EXgarde PRO license with Intruder Integration option (4420-2501)
IndigoVision System Software Requirements	IndigoVision TDSi EXgarde Integration v1.0. Compatible with SMS4™ r2 / Control Center v11.0 or later
Event and Alarm Integration Capability	Unidirectional flow of events and alarms from the TDSi EXgarde into Control Center
Alarm Acknowledgement Capability	EXgarde alarms can be acknowledged or deleted from within the Control Center interface
Integration Server Specification	PC requirements for TDSi EXgarde vary depending on the size of the access control system and the database software being used. Refer to TDSi documentation for advice on machine specifications. The IndigoVision TDSi EXgarde Integration may run on the same PC as TDSi EXgarde or on a separate PC. There are no extra requirements on the specification of the PC due to the IndigoVision software. NOTE: The Integration is a licensed product. A software license key must be present on the platform running the Integration. The Integration should not be run on the same server as any other licensed IndigoVision software such as the Windows NVR-AS 13.2 or earlier or License Server.
Supported Products	EXgarde Pro, MicroGarde®, EXcel, EXPert, MIFARE, Proximity reader, Biometric readers, Magnetic readers
Supported Operating Systems	Microsoft® Windows Server 2016®, Microsoft® Windows Server 2012 R2®, Microsoft® Windows Server 2012®, Microsoft® Windows Server 2008 R2®, Microsoft® Windows 10® (64-bit), Microsoft® Windows 8.1® (64-bit), Microsoft® Windows 7® (64-bit)

Key Features

View Live Events

- Must be configured as an operator alarm
- You can configure cameras within IndigoVision's Control Center to be associated with zones & detectors for the integration
- Track access control events live
- Apply filters for selected / relevant access points, create filters for different zones. Users can create zones for different access points
- You can create filters for different zones. Users can create zones for different access points

Full door Control

- View alarms for: door open / closed / locked / unlocked / server connected or disconnected

Use of Maps

- Track access control events live if they're set up as an Operator Alarm

Alarm Handling

- Access control events can trigger alarms in integrated alarm management function including:
 - Alarm lists
 - Instant access to relevant video
 - Email sending
 - Start recording
 - Move a PTZ Camera

Investigate Incidents

- Investigate individual access control events with instant playback of associated video

exgarde

