



Enrolment Reader

Quick Start Guide

QS003_4

W: www.tdsi.co.uk T: 01202 723 535 E: support@tdsi.co.uk

Operation

1. At the software's Explorer Card entry point, where you would normally type in the card number, present the card to the Desktop Enrolment Reader.
2. The card number should be entered into the text field automatically.
3. Use the Caps Lock key to toggle reader operation mode.

Green Led – MIFARE Technology

Red Led – Proximity Technology

Green & Red – Dual Technology

You can also test the reader using MSWord or any text editor to verify that it reads a card and provides keyboard emulation.

Introduction

Thank you for purchasing TDSi's USB Desktop Enrolment Reader. This product provides an easy-to-use method of enrolling cards onto your Access Management software. The reader utilises a USB connection and simulates keyboard entry whenever a card is presented within its read range.

Installation

1. Connect the reader to a vacant USB port on the enrolment PC.
2. Check enrolment PC installs and recognises the reader before operation.

Specification

Power Requirements	USB powered 4.4V - 5.25V
Operating Frequency	125kHz/13.56 MHz
Card technology	EM4102/Mifare compatible
Sounder	Integral
Read Range	<80mm with ISO card, <30mm with tag
Output formats	Keyboard simulation
LEDs	Green and Red with independent control
Operating temperature range	0C - +50°C, 0 to 95 %RH (non-condensing)
Dimensions	148 x 97 x 36mm